

Spectrom is proud to announce a diaphragm installation tool to aid in the repair of AODD Pumps to our Distribution Network **release**

- **Vacuum Generator Diaphragm Inverter Tool**
 - P/N SDI-000

The vacuum pump is pneumatically operated. It is connected to the inlet or discharge of your pump air distribution system and the source air which causes one air chamber to be evacuated and shift the diaphragm assembly to the side of the pump requiring the final liquid chamber installation.

This process allows you the shift the pump without the use of pry bars which ensures that the diaphragms are not damaged and the diaphragm bead is able to be seated in the diaphragm groove while the liquid chamber is installed.

See the instructional video on-line: www.spectromparts.com & www.twitter.com/spectromparts

Benefits:

- Installation ease without the use of pry bars
- No chance of damage to the diaphragms

For questions and comments contact:

Lagos Castañeda – General Manager 909-422-1730
lagos.castaneda@spectromparts.com

Jim Trainer – Spectrom Specialist 909-422-1730
jim.trainer@spectromparts.com

Dwane Lamb – Director of Spectrom Aftermarket Parts
dwane.lamb@spectromparts.com

22069 Van Buren Street, Grand Terrace, CA 92313
Tel 909.512.1261 • Fax 909.512.1275

www.spectromparts.com

